WINTERIZATION AND SUMMER STEP-BY-STEP

0

BOREAS CAMPERS

> info@boreascampers.com 720.515.3492 5774 Lamar St. Arvada, CO 80002 www.boreascampers.com

CAMPIS WHERE YOU TOW IT

WINTERIZATION



STEP ONE

Raise the tongue to its highest point.

STEP TWO

Open the valve on the rear of the tank to get the last of the water out and close valve back once drained.



WINTERIZATION (CONTINUED)



STEP THREE Add 2 gallons of RV anti-freeze.

STEP FOUR

Run the sink and shower until you see the antifreeze solution come through and you are winterized!



SUMMER



STEP ONE

Raise the tongue to its highest point.

STEP TWO

Open the drain at the rear of the water tank and drain out the fluid. It is non toxic so it can go the ground.





SUMMER (CONTINUED)

STEP THREE

Add a tablespoon of RV tank cleaner or dish soap to remove antifreeze and fill the tank up.

STEP FOUR

Run The fresh water with cleaner through the sink and shower head. You can also open the tank valve to make this go faster.

STEP FIVE

Fill the tank again and you are good to go!

