



# Camper Readiness Checklist

- Shut Maxxair fan lid
- Turn water pump off
- Close and latch all cabin and kitchen cabinet doors
- Close and lock all doors - toolbox, cabin, back galley, shower box
- Turn propane tank(s) off
- Pull stabilizers up
- Cross chains after hitching the camper to tow vehicle
- Pull tongue wheel jack up and secure
- Disengage e-brake
- Attach emergency break-away cable
- Plug in 7-pin to tow vehicle
- Test all lights: brakes, turn signals, running, reverse